


CE
0476

FRESE CONICHE FINALI PER IMPIANTI TX40

CONICITA'  Ø 3
Ø 2,5

FX10 : Per impianti




VSO Ø 3,2 L. 8,5
VSO Ø 3,2 L. 10,0

TPA Ø 4,0 L. 8,5
TPA Ø 4,0 L. 10,0

8,5 10

FX10

FX13 : Per impianti




VSO Ø 3,2 L. 11,5
VSO Ø 3,2 L. 13,0

TPA Ø 4,0 L. 11,5
TPA Ø 4,0 L. 13,0

11,5 13

FX13

FX16 : Per impianti



VSO Ø 3,2 L. 14,5
VSO Ø 3,2 L. 16,0

TPA Ø 4,0 L. 14,5
TPA Ø 4,0 L. 16,0

14,5 16


FX16

CE
0476

FRESE CONICHE FINALI PER IMPIANTI TR48

CONICITA'  Ø 3,6
Ø 3

FY10 : Per impianti




VSO Ø 3,8 L. 8,5
VSO Ø 3,8 L. 10,0

TPA Ø 4,8 L. 8,5
TPA Ø 4,8 L. 10,0

8,5 10

FY10

FY13 : Per impianti




VSO Ø 3,8 L. 11,5
VSO Ø 3,8 L. 13,0

TPA Ø 4,8 L. 11,5
TPA Ø 4,8 L. 13,0

11,5 13

FY13

FY16 : Per impianti



VSO Ø 3,8 L. 14,5
VSO Ø 3,8 L. 16,0

TPA Ø 4,8 L. 14,5
TPA Ø 4,8 L. 16,0

14,5 16

FY16

FY Per osso duro




FY

CE
0476

FRESE CONICHE FINALI PER IMPIANTI TR60

CONICITA'  Ø 4,2
Ø 3,5

FZ10 : Per impianti




VSO Ø 4,4 L. 8,5
VSO Ø 4,4 L. 10,0

TPA Ø 6,0 L. 8,5
TPA Ø 6,0 L. 10,0

8,5 10

FZ10

FZ13 : Per impianti




VSO Ø 4,4 L. 11,5
VSO Ø 4,4 L. 13,0

TPA Ø 6,0 L. 11,5
TPA Ø 6,0 L. 13,0

11,5 13

FZ13

FZ16 : Per impianti



VSO Ø 4,4 L. 14,5
VSO Ø 4,4 L. 16,0

TPA Ø 6,0 L. 14,5
TPA Ø 6,0 L. 16,0

14,5 16

FZ16

FZ Per osso duro



FZ