


CE 0476

# FRESE CONICHE FINALI PER IMPIANTI VX32

CONICITA'  Ø 3  
Ø 2,5

**FX10** : Per impianti




VSO Ø 3,2 L. 8,5  
VSO Ø 3,2 L. 10,0

TPA Ø 4,0 L. 8,5  
TPA Ø 4,0 L. 10,0

8,5 10

**FX10**

**FX13** : Per impianti




VSO Ø 3,2 L. 11,5  
VSO Ø 3,2 L. 13,0

TPA Ø 4,0 L. 11,5  
TPA Ø 4,0 L. 13,0

11,5 13

**FX13**

**FX16** : Per impianti



VSO Ø 3,2 L. 14,5  
VSO Ø 3,2 L. 16,0

TPA Ø 4,0 L. 14,5  
TPA Ø 4,0 L. 16,0

14,5 16


**FX16**

CE 0476

# FRESE CONICHE FINALI PER IMPIANTI VX38

CONICITA'  Ø 3,6  
Ø 3

**FY10** : Per impianti




VSO Ø 3,8 L. 8,5  
VSO Ø 3,8 L. 10,0

TPA Ø 4,8 L. 8,5  
TPA Ø 4,8 L. 10,0

8,5 10

**FY10**

**FY13** : Per impianti




VSO Ø 3,8 L. 11,5  
VSO Ø 3,8 L. 13,0

TPA Ø 4,8 L. 11,5  
TPA Ø 4,8 L. 13,0

11,5 13

**FY13**

**FY16** : Per impianti



VSO Ø 3,8 L. 14,5  
VSO Ø 3,8 L. 16,0

TPA Ø 4,8 L. 14,5  
TPA Ø 4,8 L. 16,0

14,5 16

**FY16**

**FY** Per osso duro




**FY**

CE 0476

# FRESE CONICHE FINALI PER IMPIANTI VR44

CONICITA'  Ø 4,2  
Ø 3,5

**FZ10** : Per impianti




VSO Ø 4,4 L. 8,5  
VSO Ø 4,4 L. 10,0

TPA Ø 6,0 L. 8,5  
TPA Ø 6,0 L. 10,0

8,5 10

**FZ10**

**FZ13** : Per impianti




VSO Ø 4,4 L. 11,5  
VSO Ø 4,4 L. 13,0

TPA Ø 6,0 L. 11,5  
TPA Ø 6,0 L. 13,0

11,5 13

**FZ13**

**FZ16** : Per impianti



VSO Ø 4,4 L. 14,5  
VSO Ø 4,4 L. 16,0

TPA Ø 6,0 L. 14,5  
TPA Ø 6,0 L. 16,0

14,5 16

**FZ16**

**FZ** Per osso duro



**FZ**